



DanVex AD-10000

Adsorption air dehumidifier

» Operation manual





CONTENT

Safety instructions.....	3
Introduction.....	4
Purpose.....	4
Operation principle.....	4
Design.....	5
Dimensions and weight.....	5
Installation.....	6
Technical data.....	7
Commissioning.....	7
Maintenance.....	11
Transportation.....	12
Parts list.....	12
Attachment.....	13
Warranty obligations.....	16

Safety instructions

AD series dehumidifiers meet all the requirements stated in European safety regulations and standards.

All persons admitted to operate or maintain the DanVexAD-10000 dehumidifiers should read these instructions manual and to be briefed for its safe operation.

Only the personnel with sufficient knowledge of the dehumidifiers operation principle is permitted to perform the adsorption dehumidifiers operation and maintenance.

Only authorized personnel with special education is permitted to perform maintenance and repair works on electrical system.

Only authorized service center personnel is permitted to perform repair works on electrical components.

It is prohibited to install or operate the units in the locations subject to explosion hazard..

Before opening any panels of the unit body it is required to disconnect the dehumidifier from the mains.

Before starting any maintenance works the dehumidifier should be out-of-operation for 15 minutes.

The unit's panels must be always closed except when the dehumidifier is being maintained.

The dehumidifier can be used for air drying at atmospheric pressure only.

Never use the dehumidifier without filters since the drying rotor can get contaminated which will cause loss of efficiency.

This manual should always be at hand and not far from the dehumidifier.

The dehumidifier maintenance and inspection works should be performed in accordance with a fixed schedule.

Only original spare parts should be used.

It is required to receive a written approval from «DanVex Oy» or from its local representative for any changes or modifications of the dehumidifier.

Introduction

This specification is a technical document that certifies the DanVexAD-10000 dehumidifier parameters and characteristics.

Purpose


DanVexAD-10000 (in short AD-10000) is designed for efficient air dehumidification with the air humidity up to 100%, at the temperature from -20°C to $+40^{\circ}\text{C}$ with minimum energy consumption. It can be used either as an independent unit for installation inside and outside of premises where air humidity control is required or along with an air treatment system.

Operation principal

The main dehumidifier part is a rotor having a cellular structure made from fibrous ceramic material and SelicaGel. The rotor is divided into two zones by a sealing device: one for dehumidification, another for regeneration.

Thus, the dehumidifier works with two air flows. The volume of the dehumidified air is bigger. The air flow of a smaller volume is used for moisture removal from the dehumidifier rotor. The rotor is subject to the action of different oppositely directed air flows by sectors. The air flow to be dehumidified (PROCESS AIR) passes through the biggest sector. The moisture from the air is trapped (adsorbed) by the rotor material. The air leaves the rotor in dehumidified condition (DRY AIR) and is directed to a certain part of the building or a technological process where dehumidified air or a certain air humidity levels are required. Since the rotor rotates slowly the incoming air always contacts with the rotor active part, thus a continuous dehumidification process is assured.

The air flow used for the rotor regeneration is called regeneration air (REGENERATION AIR). It is heated up to 140°C and when passing through a small sector it removes the moisture trapped by the rotor material. The moisture is removed from the rotor in the form of humid air (MOIST AIR) which is discharged outside the dehumidified loop



- The air to be dehumidified passes through the rotor. Water molecules are absorbed by the rotor.
- The rotor is reactivated by another air flow preheated to 140°C . The moisture is removed from the room in the form of moist air.

Pic.1. Dehumidifier air flows diagram

Design

The dehumidifier answers IP 44 protection class according to IEC.

Body

The dehumidifier body is made of stainless zinc-plated steel. It is thermally insulated which allows the dehumidifier to be used in low-temperature premises and prevents condensate formation inside the dehumidifier.

The body has a frame structure which allows easy moving of the dehumidifier during transportation and installation.

The dehumidifier is equipped with detachable panels and doors that assure access for maintenance and repair.

The rotor drive belt tension mechanism and a sealing system assures the dehumidification reliable and efficient operation.

Rotor

The dehumidifier is equipped with a drying rotor manufactured in accordance with unique technologies covered by a patent in force. The rotor represents a matrix consisting of numerous air channels. It is made of composite material with introduced active SelicaGel and assures a very large contact area with air flow for moisture adsorption in the small volume of the rotor. This material is highly efficient for water molecules attraction and retention, it is noncombustible and explosion-proof, with a long service life. The rotor manufacturing technology assures production of a product capable of saturated air processing without risk of destruction, it means that the rotor can be used along with a precoolers. Besides, the rotor will not be damaged even if the fan or the reactivation air heater fail to function.

Filters

The dehumidifier is equipped with two filters. One filter is located at the dehumidified air inlet, the another one is installed at the reactivation air inlet.

Air flow fans: for dehumidified air flow and for reactivation air flow

The fans are of a radial type, single phase, IP 54 class, ISO F. The fans maintenance can be performed after the service panels are removed.

Electric panel

Electrical components are located inside the dehumidifier and can be reached through detachable or opening panels. Switches and indicators are located in the front part of the dehumidifier.

Reactivation air heater

The reactivation air heater consists of a heating element.

Control panel


DanVex AD-10000 dehumidifier is equipped with an automatic control system. All commands are input using the buttons located on the control panel with a LCD-display.

Dimensions and weight

Insignificant design changes are possible!

Table 1

Length	Depth	Height	Dehumidified air	Dry air	Reactivation air	Moist air	Weight
2250mm	1650mm	1800mm	ø 630 mm	ø 630 mm	ø 315 mm	ø 315 mm	980 kg



Pic. 2. AD-10000 dehumidifier dimensions

Installation

Installation and the covered area

AD-10000 dehumidifier is designed for indoor installation. It should be positioned upright on an even surface. It is recommended to fix the dehumidifier. It is required to leave some free space (1500 mm) in front and above the dehumidifier for filters, fans and rotor maintenance and inspection.

Channel connections for permanent installation

The dehumidifier can be installed directly in the room to be dehumidified or in a separate ventilation chamber. In case of special versions it can be placed outdoors as well. To assure better parameters and efficiency the air outlets should be equipped with diffusers.

Moist air duct

Moist air should be discharged outside the dehumidified loop (to outdoors). The air duct should be as short as possible to minimize the possibility of condensation of the moisture from the moist air. The duct should be slightly inclined downwards to prevent the condensate entering the equipment. In case it is required to install the moist air duct upright it should be insulated and drain holes should be drilled in the lowest part of the elbow bend (2-4 mm).

Regeneration air duct

The regeneration air duct should be as short as possible. A metal net is installed at the duct input to prevent foreign matters entering the dehumidifier. There is no need to insulate the duct. The duct inclination angle is optional.

Dehumidified and dry air ducts at the dehumidifier installation inside the dehumidified loop

As a rule in case the dehumidifier is installed in the dehumidified loop air ducts for the air intake are not required. A dry air duct is connected with the air-ducting system for dry air distribution inside the premises.

Dehumidified and dry air ducts at the dehumidifier installation outside the dehumidified loop

In case the dehumidifier is installed outside the dehumidified loop either a recirculation or an open circuit is used. If a recirculation circuit is used the air to be dehumidified is supplied from the loop via an air duct and the dehumidified dry air is supplied to the dehumidified room the same way. If an open dehumidification circuit is used only dry air is supplied to the room.

Electrical connection

Please see the attached electric diagram

Technical data of AD-10000

Table 2

Parameter	Unit	Value
Dehumidified air* Rated air consumption Pressure	m ³ /hour Pa	10000 500
Reactivation air* Rated air consumption Pressure	m ³ /hour Pa	3500 250
Electric power and rated current Total power Voltage (3 phase, 50 Hz)	kW V	80 380/400
Reactivation air heater Heater capacity Heater type	kW -	70 Tubular Heating Element
Miscellaneous data Maximum sound pressure level Operational temperatures range Standard filter: dehumidified air Reactivation air IEC protection, the whole dehumidifier	dB(A) °C - - -	65 -20...+40 EU3 EU3 IP44
* The above mentioned values are nominal based on the air temperature of 20°C and the air density of 1,2kg/m ³		


Commissioning

Start up procedures:


1. Make sure the dehumidifier is disconnected from the power supply source and that its main switch is in OFF position.
2. Open the dehumidifier service panels and make sure there are no foreign matters inside the dehumidifier.
3. Make sure all air throttles are opened and that channels are clean and not blocked.
4. Make sure that air filters are installed and clean.
5. Manually turn the fans impellers and make sure they rotate freely.
6. Check the internal fuse.
7. Close the service panels and connect the dehumidifier to 380/400V power supply.
8. Switch on the dehumidifier power supply. The following will be displayed on the control panel LCD:




9. Press «F1» to start the dehumidifier. The dehumidifier will start with default settings. Use «F4» button to stop the dehumidifier. It should be noted that after switching off the fans and the rotor continue operation for 5-10 minutes to prevent the overheating protection tripping.




10. Press «ESC» to enter the setting menu «Setting data 1». Enter temperature, relative humidity and regeneration temperature by pressing «▼» or «▲» buttons till the required values are set. Press «ENTER».




11. Press «▼» or «▲» for navigation, correction of temperature and relative humidity range. Press «ENTER».



12. Press «▼» or «▲» for correction of regeneration air and process air temperature range. Press «ENTER».



13. Press "ESC" to enter the "Working mode 1" menu to get information on the operation conditions of process air fans, regeneration air fan, rotor and heater motor.




Alarm signals


In the dehumidifier there are two types of alarm signals: the first type is used to announce about serious failures, the second type is used to announce about minor problems.

In case of a serious problem a buzzer will sound, the failure cause will be displayed on the screen and the dehumidifier will stop. In case of a minor problem a buzzer will sound and the failure cause will be displayed on the screen.

An acoustic signal is the indication of improper operation. Press «F2» to switch the acoustic signal off. Press «ENTER»







Maintenance

The dehumidifier can operate for a long time providing the maintenance schedule is observed. The maintenance schedule depends on its operational environment, air contamination level and installation place. It can be corrected based on the actual conditions.

Improper maintenance and service can cause the reduction of the dehumidification efficiency and the humidifier components failure.

ATTENTION! For the dehumidifier maintenance:

Turn off the dehumidifier 15 minutes before the front service panel is opened. It will allow the dehumidifier to cool down.

Disconnect the dehumidifier from the mains by turning the switch to OFF position and disconnecting the power plug from the mains socket.

Filters

The dehumidifier is equipped with two separate filters, one for process air and one for regeneration air. The filters are located in front of their appropriate inputs and are used for cleaning of the air entering the dehumidifier.

The filters cleaning and replacement intervals are based on the amount of dust and particles in the air at the place of installation. It is recommended to check the filters at least once per month.

Never use the dehumidifier without filters.

Rotor

The rotor is maintenance free. However for cleaning purposes it can be flushed out by compressed air. A rotor cleaning procedure requires special knowledge, for this reason it is recommended to call the manufacturer's representative for assistance. The rotor bearing and the rotor surface should be checked once a year.

Motors

The motors are maintenance free.

It is required to check the motors once a year or in case of abnormal sound.

Heater

The regeneration heater is maintenance free, however twice a year it should be checked for mechanical damages.

Rotor belt

It is required to carry out regular inspections of the belt tension.

Seals

It is required to carry out regular inspection of the seals for damage and dust contamination.

Transportation

Please observe the following rules of the dehumidifier transportation and storage:

Upon delivery it is required to check the dehumidifier for transportation damages.

The dehumidifier should be protected from rain and snow.

The dehumidifier should always be in upright condition.


It is not allowed to put heavy objects on the dehumidifier.


Parts list

Table 3

Name	Number per dehumidifier
Rotor drive motor	1
Condenser	1
Belt pulley	1
Rotor drive belt	1
Belt tensioner	1
Dehumidified air fan	1
Regeneration air fan	1
Heater	1
Rotor	1

Attachment





A	1	2	3	4	5	6	7	8																																																																																																									
B	<div style="display: flex; justify-content: space-between;"> <div> <p>XT</p> <table border="1"> <tr> <td>1</td> <td>DC24V+</td> <td>L+</td> </tr> <tr> <td>2</td> <td>COM</td> <td>M</td> </tr> <tr> <td>3</td> <td>COM</td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> </tr> <tr> <td>5</td> <td></td> <td></td> </tr> <tr> <td>6</td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> </tr> <tr> <td>8</td> <td></td> <td></td> </tr> <tr> <td>9</td> <td></td> <td></td> </tr> <tr> <td>10</td> <td></td> <td></td> </tr> <tr> <td>11</td> <td></td> <td></td> </tr> <tr> <td>12</td> <td></td> <td></td> </tr> <tr> <td>13</td> <td></td> <td></td> </tr> <tr> <td>14</td> <td></td> <td>L+</td> </tr> <tr> <td>15</td> <td></td> <td></td> </tr> </table> </div> <div> <p>Current temp ALW0+ ALW0- ALW2+ ALW2- RH Regen air temp ALW4+ ALW4- Wet air temp ALW6+ ALW6- Spare L+ PIR Remote KAI-2 Alarm KAI-2</p> </div> </div>								1	DC24V+	L+	2	COM	M	3	COM		4			5			6			7			8			9			10			11			12			13			14		L+	15																																																														
1	DC24V+	L+																																																																																																															
2	COM	M																																																																																																															
3	COM																																																																																																																
4																																																																																																																	
5																																																																																																																	
6																																																																																																																	
7																																																																																																																	
8																																																																																																																	
9																																																																																																																	
10																																																																																																																	
11																																																																																																																	
12																																																																																																																	
13																																																																																																																	
14		L+																																																																																																															
15																																																																																																																	
C	<div style="display: flex; justify-content: space-between;"> <div> <p>SSR1 diagram</p> </div> <div> <p>SSR1 diagram</p> </div> </div>																																																																																																																
D	<table border="1"> <tr> <td>21</td> <td>EM</td> <td>Shutter stop</td> <td>LA1D-1IN</td> <td>PC 1</td> </tr> <tr> <td>20</td> <td></td> <td>Auxiliary contact</td> <td>PC 1</td> <td></td> </tr> <tr> <td>19</td> <td></td> <td>Power</td> <td>PC 1</td> <td></td> </tr> <tr> <td>18</td> <td>SB1, SB2</td> <td>Button</td> <td>PC 2</td> <td></td> </tr> <tr> <td>17</td> <td>FJ</td> <td>Heat Radiator fan</td> <td>PC 1</td> <td></td> </tr> <tr> <td>16</td> <td>SP</td> <td>Operation screen</td> <td>PC 1</td> <td></td> </tr> <tr> <td>15</td> <td>BK25</td> <td>Analog Module</td> <td>PC 1</td> <td></td> </tr> <tr> <td>14</td> <td>CPU</td> <td>PLC</td> <td>PC 1</td> <td></td> </tr> <tr> <td>13</td> <td>HA</td> <td>Buzzer</td> <td>PC 1</td> <td></td> </tr> <tr> <td>12</td> <td>SSR1</td> <td>Solid state relay</td> <td>SSR-3H380D75</td> <td>PC 1</td> </tr> <tr> <td>11</td> <td>KAI</td> <td>Intermediate relay</td> <td>AC220V</td> <td>PC 1</td> </tr> <tr> <td>10</td> <td>KI3</td> <td>Thermal relay</td> <td>6*8A</td> <td>PC 1</td> </tr> <tr> <td>9</td> <td>KI2</td> <td>Thermal relay</td> <td>0.25A</td> <td>PC 1</td> </tr> <tr> <td>8</td> <td>KI1</td> <td>Thermal relay</td> <td>2.5-4A</td> <td>PC 1</td> </tr> <tr> <td>7</td> <td>KM4, KM5</td> <td>Cocontactor</td> <td>LC1DBN7C</td> <td>PC 2</td> </tr> <tr> <td>6</td> <td>KM1, KM3</td> <td>Cocontactor</td> <td>LC1DBN7C</td> <td>PC 3</td> </tr> <tr> <td>5</td> <td>QF8</td> <td>Molded case switch</td> <td>125A</td> <td>PC 1</td> </tr> <tr> <td>4</td> <td>QF6, QF7</td> <td>Beaker</td> <td>QF6-Q3/1P</td> <td>PC 2</td> </tr> <tr> <td>3</td> <td>QF4, 5</td> <td>Beaker</td> <td>QF6-Q3/3P</td> <td>PC 2</td> </tr> <tr> <td>2</td> <td>QF3</td> <td>Beaker</td> <td>QF6-Q3/3P</td> <td>PC 1</td> </tr> <tr> <td>1</td> <td>QF1, 2</td> <td>Beaker</td> <td>QF6-Q3/3P</td> <td>PC 2</td> </tr> </table>								21	EM	Shutter stop	LA1D-1IN	PC 1	20		Auxiliary contact	PC 1		19		Power	PC 1		18	SB1, SB2	Button	PC 2		17	FJ	Heat Radiator fan	PC 1		16	SP	Operation screen	PC 1		15	BK25	Analog Module	PC 1		14	CPU	PLC	PC 1		13	HA	Buzzer	PC 1		12	SSR1	Solid state relay	SSR-3H380D75	PC 1	11	KAI	Intermediate relay	AC220V	PC 1	10	KI3	Thermal relay	6*8A	PC 1	9	KI2	Thermal relay	0.25A	PC 1	8	KI1	Thermal relay	2.5-4A	PC 1	7	KM4, KM5	Cocontactor	LC1DBN7C	PC 2	6	KM1, KM3	Cocontactor	LC1DBN7C	PC 3	5	QF8	Molded case switch	125A	PC 1	4	QF6, QF7	Beaker	QF6-Q3/1P	PC 2	3	QF4, 5	Beaker	QF6-Q3/3P	PC 2	2	QF3	Beaker	QF6-Q3/3P	PC 1	1	QF1, 2	Beaker	QF6-Q3/3P	PC 2
21	EM	Shutter stop	LA1D-1IN	PC 1																																																																																																													
20		Auxiliary contact	PC 1																																																																																																														
19		Power	PC 1																																																																																																														
18	SB1, SB2	Button	PC 2																																																																																																														
17	FJ	Heat Radiator fan	PC 1																																																																																																														
16	SP	Operation screen	PC 1																																																																																																														
15	BK25	Analog Module	PC 1																																																																																																														
14	CPU	PLC	PC 1																																																																																																														
13	HA	Buzzer	PC 1																																																																																																														
12	SSR1	Solid state relay	SSR-3H380D75	PC 1																																																																																																													
11	KAI	Intermediate relay	AC220V	PC 1																																																																																																													
10	KI3	Thermal relay	6*8A	PC 1																																																																																																													
9	KI2	Thermal relay	0.25A	PC 1																																																																																																													
8	KI1	Thermal relay	2.5-4A	PC 1																																																																																																													
7	KM4, KM5	Cocontactor	LC1DBN7C	PC 2																																																																																																													
6	KM1, KM3	Cocontactor	LC1DBN7C	PC 3																																																																																																													
5	QF8	Molded case switch	125A	PC 1																																																																																																													
4	QF6, QF7	Beaker	QF6-Q3/1P	PC 2																																																																																																													
3	QF4, 5	Beaker	QF6-Q3/3P	PC 2																																																																																																													
2	QF3	Beaker	QF6-Q3/3P	PC 1																																																																																																													
1	QF1, 2	Beaker	QF6-Q3/3P	PC 2																																																																																																													
E	<p>Low voltage terminal drawing</p>																																																																																																																

Checked		<p>AD-5000</p>	Responsible	
Re-checked			Scale	03
Designed			No.	201308
Drewed			Date	

Warranty obligations

DanVex warrants that all the equipment parts will answer the technical requirements for 12 months from the date of delivery (warranty period).

The warranty does not cover wearable parts such as filters. The warranty covers the defects in workmanship and materials.

During the warranty period DanVex repairs and replaces the part having a defect of material or a manufacturing error.

DanVex completely fulfills its warranty obligations when it supplies the Customer a repaired or a spare part.

Parts repair or replacement does not result in the warranty period extension.

The parts and components replaced under the warranty belong to DanVex.

DanVex or its distributor upon DanVex request has a right to inspect the defective parts and to check the correctness of the warranty claim.

Warranty repair execution conditions:

The damage occurred during the equipment normal operation. All recommendations and instructions of the manufacturer concerning the equipment installation, operation and maintenance were observed. Only original parts and materials were used for the equipment maintenance and repair.



www.danvex.fi

